

DHT22 FR4 Temperature

DHT22 FR4 Temperature



Voltage: 5V; Temperature: $-40\sim 80^{\circ}\text{C}$, $\pm 0.5^{\circ}\text{C}$; Humidity: $20\sim 90\%RH$, $\pm 2\%RH$; Suitable for Arduino, SCM; A product for Arduino that works with official Arduino boards.